## Data sheet

### LED Downlight SDR-070/6W




#### Product

Model name	SDR-070
Maker	Stardust LED
Voltage	AC85V~265V(50/60Hz)
Power Consumption	6 W
Produit	LED Downlight
Driver	Include




# Lighting Data 1632 1224 816 408

SDR-070 (6W-3000K,20deg)



#### Dimensional drawing (unit: mm)



#### **Customer Benefits**

- Energy efficient LED directoinal downlight with single square trim allowing for 360° a lamp rotation.
- With a high power LED and funnel coated in patented reflective technology, this recessed downlight gives a strong, well distributed beam of light which is perfect for general lighting applications where good illumination is essential.

#### Application


Houses, Hotels, Shopping center, Museum, Shops, Office Building

#### Specifications

Model name	SDR-070
Nominal luminous flux(lm)	450 ~ 540
Frequency(Hz)	50/60
Input current(mA)	Max.200
Nominal power consumption(W)	6
Power factor	>0.9
Lumen Maintenance Factor	L70
Dimmable Function	Dimmbar
Nominal beam angle(°)	20°
Operating temperature(°C)	- 20°C ~ + 48°C
Nominal lamp life time(hrs)	50000
Color temperature(K)	2700K ~ 5000K
CRI(Ra)	>80
Rating	IP44
Dimension(mm)	Ф88 × 70
Material	Aluminum
Weight(g)	120
Energy Efficiency Index	A++
Energy consumption(kWh/1000h)	6
Certification	CE


## **LED Downlight**

Beam Angle




#### Installation Instruction


 Drill a right hole where need to install downlight. Turn off the powerswitch, connect operating voltage.



3. Insert the LED downlight to the hole like the picture schows




2. Put up spring dump before installing the downlight.





4. Completed the installation.



Contact

